


Item No.: 205897

Installation guide



Tools list

Please note the drawings below are only for reference which might be slightly different from the actual object and please be subject to actual object. Any tools missing or installation problem, please contact customer service first.


No.	Image	Spec	Qty
1		ST4.2	4
2		Allen key 5x5	1
3		M8	2

Specification

Width Range	870-1470mm
Desktop dimension	1100-1700mm



Component list

No.	Part	Qty
A	 Cable Management Tray 1	1
B	 Cable Management Tray 2	1
C	 Hook	2





STEP 1

Install hook




Ekoflex series Installation Guide



Fix the hook (C) on the side of supporting beam with screw (3) and use 5 x 5 allen key (2) to tighten. Then use hand drill to fix it on the tabletop.




Alternative 1 Installation Guide




Supporting beam




The distance between the hook and the edge of the desktop is 200 mm.




If there is no hole in the supporting beam, install the hook (C) on the tabletop and use hand drill to tighten.



Alternative 2 Installation Guide




The distance between the hook and the edge of the desktop is 200 mm.




If there is no hole in the supporting beam, install the hook (C) on the tabletop and use hand drill to tighten.

STEP 2


Install cable management tray




Method 1




Method 2




Finished product diagram



Ekoflex series Height adjustable standing desk



Alternative 1 Height adjustable standing desk



Alternative 2 Height adjustable standing desk



CAUTION

- This product contains small items that could be a choking hazard if swallowed. Keep these items away from young children.
- Make Sure these instructions are read and completely understood before attempting installation. If you are unsure of any part of this installation, please contact a professional installer for assistance.
 - Children are forbidden to play on the product because of unforeseen action when playing, so any dangerous consequences caused by this improper action will not be on response.
 - This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved. Children shall not play with the appliance.
 - Cleaning and user maintenance shall not be made by children without supervision.
 - Please make sure there is no hazard sources in your operating environment. e.g., do not litter the tools around. Always be careful to treat the packaging materials in order to avoid any possible danger, e.g. plastic bag may lead to choking hazard to children.
 - Keep the original package of the equipment if necessary in case of the future use in transportation.

