

Back height adjustment :

To rise: Hold the bottom of the chair back (①) with both hands and lift it up to a suitable height step by step.

To lower: Hold the bottom of the chair back with both hands and lift it step by step. After crossing the highest position, the back can be lowered to the lowest position.

Attention: Backrest can NOT lower down during the adjustment to upward; Only can lower down to lowest position when reaching the highest position and release your hands.

Armrest adjustment (②):

To rise or lower: Press the button while holding the armrest, lift it up or lower it down, release when reaching a desired height.

Armrest angle to left or right: Grasp the armrest and press the button under the armrest, pivot to left or right. Armrest can rotate 360 degree.


Armrest forward and backward: Grasp the armrest, slide forward or backward.

Armrest width: Turn anticlockwise the knob to unlock, grasp the armrest to pull out or push in, turn clockwise the knob to lock when reaching proper position.

Seat angle adjustment (Forward Tilt):

To adjust the seat angle: Turn clockwise the handle (③), the rear part of the seat will be lifted up, while reaching the stop point, the seat angle can be locked.

To return: Turn anticlockwise the handle, the rear part of the seat will lower down automatically.



Seat height adjustment:

To raise: Lift up the lever (④) when leaving or half up, release the lever when reaching a desired height.

To lower: While sitting, lift the lever up, release the lever when reaching a desired height.

Tilt tension adjustment:

To increase: Turn clockwise the handle (⑤) to stronger.

To reduce: Turn anticlockwise the handle to weaker.

Seat depth adjustment:

To increase: While sitting and press down the lever (⑥), push your hips forward to slide the seat cushion to a proper position, then release the lever.

To reduce: When leaving or half up, press down the lever, and the seat cushion can return to the rear position or release the lever when it reaches the desired position.

Backrest angle adjustment (Tilt Lock):

To unlock: Turn the knob (⑦) backward.

To lock: Turn the knob forward when reaching desired angle.

Attention: Mechanism with safety lock, after unlock operation, the back will not return immediately, need to recline and then can be fully unlock.